




Item No.	Part No.	Description	Q'ty
1	C148738	Adapter-1/4 in. NPT	1
2	C148739	Bushing-Air Inlet	1
3	C148740	Deflector-Exhaust	1
4	C114089	Pin-Roll	1
5	KF124508	Lever-Throttle	1
6	C148741	Valve-Stem	1
7	P083076	O-Ring-007	1
8	C148742	Spring-Valve	1
9	C148743	Retainer-Reverse	1
10	C148744	O-Ring	1
11	C148745	Screw-Valve	1
12	C148746	Valve-Reverse	1
13	C148747	Spring-Reverse Valve	1
14	C148748	Housing-Motor	1
15	CA157684	Bearing-Ball	1
16	C148749	End Plate-Upper	1
17	C148750	Pin	1
18	C148751	Cylinder	1
19	C148752	Blade-Rotor	5
20	C148753	Rotor	1
21	C148754	End Plate-Lower	1
22	S025101	Bearing-Ball	1
23	P092536	O-Ring-020	1
24	C087834	Bearing-Ball	1
25	C148755	Spacer	1
26	C148756	Spindle-Gear	1
27	C148757	Gear-Idler	2
28	C148758	Pin-Idler Gear	2

Item No.	Part No.	Description	Q'ty
29	C148759	Gear-Internal	1
30	C069511	Bearing-Ball	1
31	C148760	Collar	1
32	C148761	Nut-Adjustment	1
33	C148762	Seat-Adjustment Nut	1
34	C148763	Spring-Clutch	1
35	C148764	Seat-Clutch Spring	1
36	CA146106	Ball-Steel	14
37	C148765	Plug-Dog	1
38	C148766	Clutch-Spindle	1
39	C148767	Ball-Steel	4
40	C148768	Dog	1
42	C148769	Retainer-Dog	1
43	C148770	Spring-Center	1
44	C148771	Spindle-Output	1
45	S000821	Ball-Steel-.125" dia.	1
46	C148772	Retainer-Ball	1

	CA156071	Operator's Manual
	CA146619	Warning Label
	6159948700	Safety Instructions