

3/4" General Purpose Filter Installation & Maintenance Instructions

TECHNICAL DATA

Fluid: Compressed air
 Maximum pressure:
 Metal bowl: 17 bar (250 psig)
 Operating temperature*:
 Metal bowl: -20° to +80°C (0° to +175°F)
 * Air supply must be dry enough to avoid ice formation at temperatures below +2°C (+35°F).
 Port size: 3/4"
 Thread form: PTF, or ISO G
 Drain: Automatic
 Bowl: Metal with liquid level indicator
 Particle removal: 5 µm filter element
 Air quality: Within ISO 8573-1, Class 3 (particulates)
 Nominal bowl size: 0,2 litre (7 fluid ounce)
 Automatic drain connection: 1/8"
 Automatic drain operating conditions (float operated):
 Bowl pressure required to close drain: Greater than 0,3 bar (5 psig)
 Bowl pressure required to open drain: Less than 0,2 bar (3 psig)
 Minimum air flow required to close drain: 1 dm³/s (2 scfm)
 Materials:
 Body: Aluminum
 Bowl:
 Metal: Aluminum
 Metal bowl liquid level indicator lens: Transparent nylon
 Element: Sintered polypropylene
 Elastomers: Neoprene and nitrile

REPLACEMENT ITEMS

Service kit (includes items circled on exploded view).....8940169069
 Liquid level lens kit (34, 36, 37, 38).....8940169081
 Filter element, 5µm, red speckles (52).....8940169084
 Automatic drain (21, 22, 23) (31, 32, 33)
 1/8 NPT outlet8940169141
 G 1/8 outlet.....8940169139

INSTALLATION

- Shut-off air pressure. Install filter in air line -
 - vertically (bowl down),
 - with air flow in direction of arrow on body,
 - upstream of regulators, lubricators, and cycling valves,
 - as close as possible to the air supply when used as a main line filter,
 - as close as possible to the device being serviced when used as a final filter.
- Connect piping to proper ports using pipe thread sealant on male threads only. Do not allow sealant to enter interior of unit.
- Flexible tube with 3mm (0,125") minimum I.D. can be connected to the automatic drain. Avoid restrictions in the tube.
- Push bowl, or bowl with guard, into body and turn fully clockwise before pressurizing.

SERVICING

- Open manual drain to expel accumulated liquids. Keep liquids below baffle (51).
- Clean or replace filter element when dirty, when optional mechanical service indicator shows approximately all red, or when optional electrical service indicator provides an electrical output.

DISASSEMBLY

- Filter can be disassembled without removal from air line.
- Shut off inlet pressure. Reduce pressure in inlet and outlet lines to zero.
- Remove bowl - push into body and turn counterclockwise.
- Disassemble in general accordance with the item numbers on exploded view. Do not remove the drains unless replacement is necessary. Remove and replace only if they malfunction.

CLEANING

- Clean plastic lens (36, 47) with warm water only. Clean other parts with warm water and soap.
- Rinse and dry parts. Blow out internal passages in body (6) with clean, dry compressed air. Blow air through filter element (52) from inside to outside to remove surface contaminants.
- Inspect parts. Replace those found to be damaged.

ASSEMBLY

- Lubricate o-rings, the portion of the manual drain body (18, 28) that contacts the bowl, and the hole in the manual drain body that accommodates the stem of drain valve (19, 29) with o-ring grease.
- Assemble filter as shown on the exploded view.
- Arrows on indicator (3, 9) and body (6) must point in same direction. Screw baffle (51) onto center-post (53) until contact is made with element (52), then tighten an additional 1/4 turn. Push bowl, or bowl with guard, into body and turn fully clockwise.
- Torque Table

	Torque in N-m (Inch-Pounds)
8 (Screw)	2,8 to 3,9 (25 to 35)
32 (Nut)	2,3 to 2,8 (20 to 25)
34 (Screw)	1,7 to 2,3 (15 to 20)
53 (Center-post)	2,0 to 2,7 (18 to 24)

CAUTION

Water vapor will pass through these units and could condense into liquid form downstream as air temperature drops. Install an air dryer if water condensation could have a detrimental effect on the application.

WARNING

These products are intended for use in industrial compressed air systems only. Do not use these products where pressures and temperatures can exceed those listed under **Technical Data**.

These products are not designed for use with fluids other than air, for nonindustrial applications, or for life-support systems.

